

Treadmill

XFIT SECTOR

User's Manual



* Product specifications may differ from the photo and are subject to change without notice.

WARNING

Read all instructions carefully before using this product. Retain this owner's manual for future reference:

---When using this treadmill, keep attaching the safety pull pin rope to your clothes.

IMPORTANT: The SAFETY KEY has a magnet which is connected to the console. At the other end there is a clip that must be placed on your clothes. The treadmill only works with the safety key on the console.

---When you are running, keep your hand swinging natural, stare forward, never look a down at your feet.

---Add the speed step by step when running.

---When emergency happens, take away the "emergent stop button" immediately.

---Leave the treadmill after the running belt stop stably.

Caution: Read the assembly instruction carefully, follow the instruction when assemble.

ATTENTION

01- Before starting any exercise program, consult with your physician or health professional.

02- Check all the bolts locked.

03- Never put the treadmill in the wetness area, or it will cause troubles.

04- We take no responsibility for any troubles or hurts due to above reasons.

05- Dress sport clothes and shoes before running.

06- Do not do exercise in 40 minutes after meal.

07- To prevent hurts, please warm up before exercise.

08- Consult with doctor before exercise if you have high blood pressure.

09- The treadmill is only used for adults.

10- Provide the olds, children and handicapped with good care, guide and supervision.

11- Do not plug anything into any parts of this equipment, or it may damage.

12- Do not connect line to the middle of cable; do not lengthen cable or change the cable plug; do not put any heavy thing on cable or put the cable near the heat source; forbid using socket with several holes, these may cause fire or people may be hurt by the power.

13- Cut off the power when the equipment is not used. When the power is cut off, do not pull the power line to keep the wire unbroken.

15. Pulse monitor data may not be accurate, cannot be used for medicine. Over-exercise may cause injury, even death. If you have a feeling of dizziness, sickness or other abnormal symptoms, please stop training and consult a doctor immediately.

IMPORTANT SAFETY PRECAUTIONS

1. Plug the power cord of the treadmill directly into a dedicated grounded circuit. This product must be grounded. If it has breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock.
2. Position the treadmill on a clear, level surface. Do not place the treadmill on thick carpet as it may interfere with proper ventilation. Do not place the treadmill near water or outdoors.
3. Position treadmill so that the wall plug is visible and accessible.
4. Never start the treadmill while you are standing on the walking belt. After turning the power on and adjusting the speed control, there may be a pause before the walking belt begins to move, always stand on the foot rails on the sides of the frame until the belt is moving.
5. Wear appropriate clothing when exercising on the treadmill. Do not wear long, loose fitting clothing that may be caught in the treadmill. Always wear running or aerobic shoes with rubber soles.
6. Make sure the power supply is connected and the safety lock is effective before using the treadmill. Fit one side of the safety lock on the treadmill and clip the other side on your clothes or belt, which will enable you to pull off the safety lock promptly in an emergency.
7. Always unplug the power cord before remove the treadmill motor cover.
8. Make sure there is no less than 2*1m space behind the treadmill.
9. Keep small children away from the treadmill during operation.
10. Always hold the handrails when initially walking or running on the treadmill, until you are comfortable with the use of the treadmill.
10. Always attach the safety pull pin rope to your clothing when using the treadmill. If the treadmill should suddenly increase in speed due to an electronics failure or the speed being inadvertently increased, the treadmill will come to a sudden stop when the pull pin is disengaged from the console.
12. In case of any abnormality during the use process, please remove the safety lock immediately, grasping the handlebar and jumping onto the two edgings, then get off the treadmill after it stops.
13. When the treadmill is not being used, the power cord should be unplugged and the safety pull pin removed.
14. Put the safety key away where can not be reached by the children. Minors must be accompanied by the adults when using the treadmill.
15. Before starting any exercise program, consult with your physician or health professional. He or she can help establish the exercise frequency, intensity (target heart zone) and time appropriate for your particular age and condition. If you have any pain or tightness in your chest, an irregular heartbeat, shortness of breath, feel faint or have any discomfort while you exercise, STOP! Consult your physician before continuing.
16. If you observe any damage or wear on the mains plug or on any section of the mains lead then please have these replaced immediately by a qualified electrician – do not attempt to change or repair these yourself.

17. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

18. Put your feet on the side rail before using the treadmill, and always attach the safety pull pin rope to your clothing. Hold the handlebar before the running belt moving well (feel the running speed by your single foot before using it). To avoid loss balance, please slow down the speed to the lowest or take off the safety. And hold the handlebar to jump to the side rail when emergency or the safety key is not attached.


19. Make sure the treadmill has stopped before folding. Please don't operate it after folding the treadmill.

ASSEMBLY STEPS

Note: Assembly requires 2 people.

STEP 1:


1. Open the package, take out all parts and place the main frame on the flat ground. (NOTE: Please don't cut down the packing straps right now.)



STEP 2:

1. Connect the computer lower wire (92) and computer extension lower wire (93).
2. Insert and lock the upright tube (3L/R) on the bottom frame (1) with the hex socket screws (55) (59) and the Lock washer (80) (81).


NOTE: please don't tighten the Hex socket screw (55) (59) for the time being.



STEP 3:


1. Connect the computer extension upper wire (94) with the extension lower wire (93).
2. Lock the computer frame (4) on the upright tube (3L/R) with the hex socket screws (55) and Lock washer (80).

NOTE: please don't tighten the Hex socket screw (55) for the time being.





STEP 4:

1. Connect the wire of armrest (6) with the wire of computer frame (4) properly well.
2. Secure the armrest (6) to computer frame (4) with the hex socket screws (55) and Lock washer (80).
3. Separate armrest decorative cover(35L/R) from the opening, then put on the joint of armrest (6) and computer frame(4) respectively.
4. Tighten all hex socket screws which didn't tighten in previous steps.




STEP 5:

1. Connect the wire of Computer panel (29) and Computer frame (4) properly well. (Wires of the same order are joined together as picture A shown).
2. Using Hex socket screw (59) to secure the Panel bracket (5) on Computer frame (4).
3. Using Cross tapping screw (73) to secure the Computer panel joint cover (32) to Computer panel lower cover (30).



STEP 6:


1. Secure the protective cover (26L /R) to the bottom frame (1) with Cross tapping screw (73).
2. Stuck protective cover (37L /R) to the card slot of computer lower cover (28).



When you fold the machine:


Put your hands on place A, lift up the machine in the direction of the arrow until you hear the sound from the cylinder (14).

Note: Please unplug the power cord and make sure treadmill stopping completely before folding machine. Don't operate the treadmill after folding.



When you unfold the machine:

Grasp the place A by one hand, kick the place B of cylinder (14) with your right foot, pull the running board to the level of place C, then the running board will get down automatically.



GROUNDING METHODS

This product must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock.


This product is equipped with a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

DANGER – Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded.

Do not modify the plug provided with the product – if it will not fit the outlet; have a proper outlet installed by a qualified electrician.

This product is for use on a nominal **220-volt** circuit and has a grounding plug that looks like the plug illustrated in **sketch A** in following figure. Make sure that the product is connected to an outlet having the same configuration as the plug.

No adapter should be used with this product.




SPECIFICATIONS

Dimensions (open)	199 x 93 x 149 cm	Motor	AC 3.5 hp
Dimensions (folded)	120 x 93 x 169 cm	Incline	0-15
Belt Surface	53 x 151 cm	Input current	220V
Machine weight	113 kg	Speed Range	1.0-20 km/h
Maximum user weight	130 kg	Programs	Manual +P1-18 +U1-U3 + Bodyfat
Display	LCD 7" with blue backlight		

OPERATION INSTRUCTIONS

1. Function specifications



1.1. Start

Normal start up after 3s counting backwards.

1.2. Number of programs

Manual Modes, 18 Preset programs, 3 User setting programs, HRC1-HRC3,FAT.

1.3. Safe lock function

Remove the safety lock in any modes could rapidly slow down the treadmill till stop. “---” will be instantly displayed on the window, the buzzer buzz “Bi, Bi” sound continuously. Buttons are invalid in this condition. When the safety lock is off, at the same time press "PROG" + "MODE" key for 3s, the display switches between imperial and metric systems. Restore the safety lock, the window will display for 2s and then get into standby state, wait for inputting commands.



1.4. LCD windows display functions:

A. Speed/pulse window: Display the current running speed or current pulse.

B. INCL./PROG. Window: Display the current incline or programs.

C. TIME Window: Display the running time under manual mode or the countdown running time under mode and programmed mode.

D. DIS./CAL./STEPS Window: display distance, calorie or steps data. Display Switch every 5 seconds.

E.  window: "Lubrication" reminder. Display will light up the  icon when needed lubrication.

1.5. Key function

START, STOP, PROG, MODE, SPEED/+/-, INCLINE/+/-.

Speed shortcut: 3、6、9、12; slop shortcut: 3、6、9、12.

- ① "START" for startup, press SRATR the treadmill will run at minimal speed; "STOP" for stop, the treadmill will stop when the key pressed.
- ② PROGRAM KEY: In standby state, you can circle select the programs from Manual Mode to "P1-P18, U1-U3, HRC1-HRC3 and FAT" by pressing this key; Manual model is set for default, the default speed is 1.0 km/h, max speed set at 20km/h.
- ③ MODE KEY: In standby state, press the key to select H-1 to H-3 three different countdown modes; H-1 for time countdown mode; H-2 for distance countdown mode; H-3 for cal. Countdown mode; SPEED/+/- key may be used to setup all the countdown modes, after setting the data, press the START to run the treadmill.
- ④ SPEED+/-: for increase or decrease the speed setting; when setting the parameters, the motor runs, the keys can be used as parameter adjuster, when the motor runs, the keys can be used as incline adjuster, up 0.1km per press; when continuously press over 0.5s, it will continuously speed up or down.
- ⑤ INCLINE+/-: "INCLINE+" and "INCLINE-" are for slop adjusting, which can be used for the data setting; when the treadmill is in use, the key can be used to adjust the slop, advance 1level per press; continuously press over 0.5s, it will continuously incline or decline.
- ⑥ SPEED shortcut: 3km/h, 6km/h, 9km/h, 12km/h can be set under operation condition.
- ⑦ INCLINE SHORTCUT: 3,6,9,12 can be set under operation condition
- ⑧ VOLUME: adjust the music volume.
- ⑨ UP/NEXT: select the music truck.
- ⑩ Kilometer transform with mile: take off the safety key, press PROGRAM and MODE for three seconds at the same time.
- ⑪ **Incline studying**: Press the INCLINE+ and INCLINE-, two buttons for 3 seconds in the condition of taking away the safety key, you could study the incline. Please don't do other operation during incline study as far as possible, otherwise you will be failure.

1.6 Data display range of various parameters:

TIME: 0:00 – 99.59(MIN)
DISTANCE: 0.00 – 99.9(KM)
CALORIES: 0.0 – 999 (KC)
SPEED: 1.0 – 20.0(KM/H)
PULSE: 50 – 200 (BPM)
INCLINE: 0-15

1.7. Heart rate measurement function

While the treadmill is connected to the power, hold the pulse tester for 5s and the heart rate value will be displayed. The initial value is the actually measured heart rate, and its display range is: 50-200 times/ minutes. In the heartbeat measurement process, there will be a heart shaped icon flashing.

Heart rate displayed is for reference only and cannot be used as medical data.

1.8. Manual Modes

1.8.1. How to enter manual mode:

- A. Switch on the power supply; then, directly enter normal mode under the manual mode.
- B. In stop state, press MODE to select Normal mode, Time Countdown, Calorie Countdown and Distance Countdown modes under the manual mode.

1.8.2. Setting functions under manual mode: Time, Distance and Calorie Setting

- A. When entering the manual mode, the time is displayed as 0:00.
- B. In manual mode, press MODE to enter **Time Countdown mode**; the time window will display the time and flicker; the initial time is 30:00; set countdown time by SPEED +/- SPEED -. Time setting range: 5:00-99:00; each time of increase/ decrease will be 1: 00.
- C. In time countdown mode, press MODE to enter **Distance Countdown mode**; the initial distance will be displayed as 1.00 km; set the distance by SPEED +/- SPEED - in the range of 1.0-99.0 km/mi; each time of increase/ decrease will be 1 km.
- D. In distance countdown mode, press MODE to enter **Calorie Countdown mode**; the initial distance will be displayed as 50.0kcal; set the calorie by SPEED +/- SPEED - in the range of 20.0-990.0 kcal; each time of increase/ decrease will be 10.0 kcal.

1.8.3. Operation in manual mode:

- A. Press START and the motor will start operating after 3s of countdown; the initial speed will be 1.0km/h for metric system or 0.6mile/h for imperial system.
- B. Press SPEED +/- SPEED - to adjust speed;
- C. Press speed shortcuts to quickly set up to the speed marked on the key.
- D. When the motor is running, press STOP and the motor will slow down and stop finally;
- E. Remove the safety lock to urgently stop motor running; then, LCD window will display “---” and the buzzer will make short sound of Bi-Bi-Bi.
- F. When the set time reduces to zero or when the set calorie reduces to zero, or the set distance reduces to zero, the speed will gradually reduce till the stop of the machine, the buzzer will make short alarm “Bi-Bi-Bi”, and the speed window will display END;

5s later, the machine will return to the standby state and the buzzer will make long alarm “Bi-Bi”.

- G. Parameters not set will increase forwards and will be reset after reaching the upper limit of the display range; in manual mode, the machine will stop when the time accumulates to be more than 99: 59 (100min).

1.9. Preset Programs

Each program is divided into 16 sections; the operation time will be evenly distributed to each program section. Here below is a 18section program running diagram.

No.		Setup time / 16 = each segment of the running time															
		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
P1	SPEED	2	5	5	5	10	10	5	5	5	3	3	2	5	5	3	2
	INCLINE	0	0	1	1	1	1	2	2	2	2	3	3	3	2	2	0
P2	SPEED	2	2	7	2	2	7	7	12	4	4	12	4	4	12	4	2
	INCLINE	0	1	2	2	3	3	2	2	3	3	2	2	3	2	2	0
P3	SPEED	2	4	9	9	4	4	8	8	10	10	12	4	4	8	4	2
	INCLINE	0	1	2	3	4	5	4	5	4	2	1	2	3	2	1	0
P4	SPEED	2	6	6	6	12	12	12	12	6	6	3	3	3	5	5	2
	INCLINE	0	1	2	3	4	5	6	7	6	6	5	4	3	2	1	0
P5	SPEED	2	4	6	12	12	12	3	3	3	3	12	12	12	6	4	2
	INCLINE	0	2	4	6	4	2	1	0	1	1	2	2	2	2	3	0
P6	SPEED	2	4	5	5	6	6	8	8	6	6	8	8	6	9	6	2
	INCLINE	0	1	3	4	4	3	3	1	2	1	2	1	2	1	2	0
P7	SPEED	2	7	7	9	9	4	4	12	12	4	4	8	8	4	4	2
	INCLINE	0	1	1	2	2	3	3	4	4	3	3	2	2	1	1	0
P8	SPEED	2	2	6	6	6	8	9	10	11	12	9	5	5	5	3	2
	INCLINE	0	1	2	4	2	1	2	4	2	1	2	4	2	1	2	0
P9	SPEED	2	4	8	10	2	4	8	10	2	4	10	2	4	10	4	2
	INCLINE	0	1	2	3	4	5	6	7	8	9	8	6	4	2	1	0
P10	SPEED	2	5	6	7	8	9	10	11	10	9	8	6	7	5	4	2
	INCLINE	0	1	2	4	6	6	6	4	4	4	2	2	2	1	1	0
P11	SPEED	2	5	6	7	9	9	6	9	6	9	6	10	6	10	7	2
	INCLINE	0	2	2	2	3	3	3	4	4	4	5	5	5	4	4	0
P12	SPEED	2	6	8	10	8	6	4	6	8	12	8	6	8	12	12	2
	INCLINE	0	1	1	3	3	5	5	7	7	5	5	3	3	1	1	0
P13	SPEED	2	12	4	12	4	12	4	12	4	12	4	12	4	12	4	2
	INCLINE	0	8	10	13	4	8	10	13	4	8	10	13	4	8	10	0
P14	SPEED	2	8	10	12	4	8	10	12	4	8	10	12	4	8	10	2
	INCLINE	0	8	12	13	4	8	12	13	4	8	12	13	4	8	12	0
P15	SPEED	2	12	10	8	12	12	10	8	12	12	10	8	12	12	10	2
	INCLINE	0	3	4	5	6	8	7	8	8	7	7	6	5	4	3	0
P16	SPEED	2	12	4	12	4	12	4	12	4	12	4	12	4	12	4	2
	INCLINE	0	4	5	6	2	4	5	6	2	4	5	6	2	4	5	0

P17	SPEED	2	4	6	8	10	12	12	2	4	6	8	12	12	10	6	2
	INCLINE	0	4	6	8	10	12	13	12	13	12	13	10	8	6	4	0
P18	SPEED	2	6	8	4	6	8	4	6	8	4	6	8	4	6	8	2
	INCLINE	0	6	8	2	6	8	1	6	8	2	6	8	1	6	8	0

1.10. User-setting programs:

Beside the 18 inner systems, the treadmill setup 3 user-defined programs: U1, U2, U3.

1. Setting the user-defined program:

Continuously press "PROG" key until the expected program (U1/U2/U3) display in the standby condition, while the "time" window flash, display the setting time, press "SPEED+", "SPEED -" to set up expected run time, press "MODE" key to enter program parameter, then set up the first time period parameter, by "SPEED +" /" SPEED -" key or shortcut key to set the speed; press "mode" key to finish the first time period setting, and entering the next time period setting, until all 16 time period setting. The parameter will be kept permanently until resetting, and all parameter will not be lost when power off.

2. Selection and start the user-defined program:

In the standby condition, continuously press "PROG" key until the expected user-defined program U1/U2/U3 display, set up the run time, press "start" key to turn on the treadmill.

1.11. Body Fat Test:

In standby state, press PROG to enter FAT (Physical fitness test) program. Press MODE to enter the program of F—1, F—2, F—3, F—4, F—5 (F—1:gender, F—2:age, F—3:height, F—4:weight, F—5:physical test), Press SPEED +/ SPEED - to set the parameter of 01-04(see below detailed table), then press MODE to enter the program of F—5 for physical test. At this state, hold the handle pulse board for 5-6 seconds and it will display the FAT, check if the weight matches with your height.

FAT is to measure the relevance between height and weight, not the body proportion. FAT is suitable for every man and woman, it provides the important grounds for adjusting the weight with other health indicators. The perfect FAT is between 20-24, which means if less than 19 is too thin and if between 25-29 is overweight and if more than 30 is obesity.

F--1	Gender	01(man)	02(woman)
F--2	Age	10-----99	
F--3	Height	100-----200	
F--4	Weight	20-----200	
F--5	FAT	≤19	Underweight
	FAT	=(20--24)	Normal weight
	FAT	=(25--29)	Overweight
	FAT	≥30	Obesity

1.31. Others

1.13.1. When a countdown parameter run off, display "END", the alarm rings 0.5s every 2s, until the treadmill full stop, then return to manual mode.

1.13.2. In setting a parameter, it can be loop-setting, for example, time range is 5:00--99:00, when set at 99:00, press "+" key, the time return to 5:00, and so on recirculation, add or reduce by "+"—"symbol.

1.13.3. Countdown time, countdown calorie and countdown distance can only be set up for one of them. The last time setting will be implemented. The parameter set will be counted backwards while other parameters will be counted forwards.


1.13.4. The standard calorie is about 70.3kcal/km.

1.13.5. The acceleration is 0.5Km/S and the deceleration is 0.5Km/S.

1.13.6. MP3 music audio amplification, input from the enter hole by the side.

1.13.7. In the process the un-set parameter will be up cumulative, the display clear when up to the max range; in the manual mode when the time accumulation excess 99:59(100min) the treadmill stops.

1.14. "Lubrication" reminder:

Treadmill total working after Every 300KM, the screen will light up the  icon. Standby, remove the safety key then hold the 'STOP' button simultaneously till "Bi Bi" buzz comes will cancel this reminder. 300KMs later, the loop runs again.

THE WARRANTY IS NOT VALID IF: The machine is placed outdoors or exposed to sun and dust. Dust and fluff enter the internal mechanical parts of the machine, causing serious damage. Keep the machine free of dust and fluff.

CAUTION! The company does not have no responsibility for causing damage due to misuse of the product and non-compliance with the instructions for use.

CAUTION! The use of a protective carpet (plastic carpet or thin carpet) under the fitness machine is considered essential for its proper use, avoidance of vibrations and protection of the floor. The company does not bear any responsibility for causing damage due to misuse of the product and non-compliance with the instructions for use.

Check and tighten the screws at regular intervals, as they may loosen due to vibrations. Damage that may be caused by a lack of maintenance is not covered by the warranty.


EXERCISE INSTRUCTIONS

1. The Warm Up Phase

This stage helps get the blood flowing around the body and the muscles working properly. It will also reduce the risk of cramp and muscle injury. It is advisable to do a few stretching exercises as shown below. Each stretch should be held for approximately 30 seconds, do not force or jerk your muscles into a stretch - if it hurts, **STOP**.

2. The Exercise Phase

This is the stage where you put the effort in. After regular use, the muscles in your legs will become Stronger. Work to your but it is very important to maintain a steady tempo throughout. The rate of work should be sufficient to raise your heart beat into the target zone shown on the graph below.



This stage should last for a minimum of 12 minutes though most people start at about 15-20 minutes.

3. The Cool Down Phase

This stage is to let your Cardio-vascular System and muscles wind down. This is a repeat of the warm up exercise e.g. reduce your tempo, continue for approximately 5 minutes. The stretching exercises should now be repeated, again remembering not to force or jerk your muscles into the stretch.

As you get fitter you may need to train longer and harder. It is advisable to train at least three times a week, and if possible space your workouts evenly throughout the week.

To tone muscle while on your Treadmill you will need to have the resistance set quite high. This will put more strain on our leg muscles and may mean you cannot train for as long as you would like. If you are also trying to improve your fitness you need to alter your training program. You should train as normal during the warm up and cool down phases, but towards the end of the exercise phase you should increase resistance, making your legs work harder than normal. You may have to reduce your speed to keep your heart rate in the target zone.

The important factor here is the amount of effort you put in. The harder and longer you work the more calories you will burn. Effectively this is the same as if you were training to improve your fitness, the difference is the goal.



MAINTENANCE INSTRUCTIONS

WALKING BELT CENTERING AND TENSION ADJUSTMENT

DO NOT OVERTIGHTEN the walking belt. This may cause reduced motor performance and excessive roller wear.

TO CENTER WALKING BELT:

- Place treadmill on a level surface
- Run treadmill at approximately 3.5 mph
- If the belt offs the track to the right side, please screw the right adjusting bolt clockwise slowly, noticing the change of the deviating distance, until center the belt. (Attention: the space between the belt and the right/left edgings is at a distance normally. And the gap between the right and left distance should be no more than 5mm.
- If the belt offs the track to the left side, please screw the left adjusting bolt clockwise slowly, noticing the change of the deviating distance, until center the belt. (Attention: the space between the belt and the right/left edgings is at a distance normally. And the gap between the right and left distance should be no more than 5mm.



Picture A: If the belt has drifted to the RIGHT

Picture B: If the belt has drifted to the LEFT

TENSIONING THE BELT

If you can feel a slipping sensation when running on the treadmill, the running belt must be tightened. In most cases, the belt has stretched from use, causing the belt to slip. This is a normal and common adjustment. To eliminate this slipping, tension both the rear roller bolts with the appropriate size allen wrench, turning it **1/4 TURN** to the right as shown. Try the treadmill again to check for slipping.

Repeat if necessary, but **NEVER TURN** the roller bolts more than **1/4 turn** at a time. The belt tension is set properly when the running belt is **50 - 75mm** from the deck.

WARNING: ALWAYS UNPLUG THE TREADMILL FROM THE ELECTRICAL OUTLET BEFORE CLEANING OR SERVICING THE UNIT.

CAUTION! During exercise, heavy sweating can cause mechanical and electrical damage to the machine. Like any other liquid substance, sweat can cause damage mainly to the electrical parts of the machine (dial, cables, etc.). The best solution is to use a towel during exercise and wipe the machine after each use to avoid any unwanted damage.

LUBRICATION INSTRUCTIONS

WARNING! Always unplug the power cord before performing any maintenance on your treadmill.

CLEANING: Regular cleaning of your treadmill will extend its life.

WARNING! To avoid electric shock, make sure the treadmill is off and the power cord is unplugged before cleaning or maintenance.

AFTER EVERY EXERCISE: Wipe the console and other surfaces of the treadmill with a clean, dry soft cloth to remove excess sweat. **DO NOT USE CHEMICALLY.**

WEEKLY: The use of a machine protective floor or mat is recommended for ease cleaning. The dirt from the shoes comes in contact with the moving belt and eventually penetrates the bottom. The use of a vacuum cleaner under the treadmill is recommended once a week.

MONTHLY: put a broom under the treadmill to prevent dirt or trash from accumulating.


WOODEN PLATFORM LUBRICATION: Periodic lubrication control of the belt is recommended to ensure the optimal performance of the treadmill. Every 1 month, or 20 - 40 hours of operation, lift the ends of the drive belt and touch the top of the wooden platform as far as your hand can reach. If you feel traces of silicone, you do not need lubrication. If you feel the wooden surface is dry, you need lubrication. Ask your seller or call the technical department for the type of silicone.

HOW TO LUBRICATE PLATFORM

Caution: Get the right product for lubricating the drive belt. Do not use grease or anti-rust liquid or any other spray.

1. Put the spray nozzle on the lubrication spray head.
2. While lifting the drive belt on one side, place the spray nozzle between the drive belt and the wooden platform about 10cm from the front of the treadmill. Apply the silicone spray to the wooden platform, moving back and forth. Repeat for the other side of the drive belt. Spray for about 4 seconds on each side.
3. Run the treadmill for 2 minutes at a speed of 5 km / h so that the silicone is spread over the entire wooden surface and then you can use the treadmill normally.

WARNING: Do not over-lubricate the wooden platform. Excess lubricant should be wiped with a clean towel.



WARNING: The friction of the platform with the treadmill plays an important role in the operation and life of the treadmill and for this reason we recommend that you keep the treadmill clean and frequently lubricate this point of friction to extend the life of the treadmill. If you do not follow the above, the validity of the guarantee ceases.

PART LIST

Part No.	Description	Qty	Part No.	Description	Qty
1	Bottom frame	1	57	Hex socket screw M8*45	1
2	Main frame	1	58	Hex socket screw M8*40	3
3 L/R	Upright tube	1/1	59	Hex socket screw M8*15	7
4	Computer frame	1	60	Hex head cap screw M10*35	4
5	Panel bracket	1	61	Hex head cap screw M8*25	2
6	Armrest	1	62	Hexagon socket head cap screws M6*45	1
7	Incline frame	1	63	Hexagon socket head cap screws M6*55	2
8	Strengthen tube	1	64	Hexagon socket head cap screws M6*10	2
9	Transport wheel bracket	2	65	Hexagon inner head bolt M6*30	4
10	Front roller	1	66	Hexagon inner head bolt M6*25	4
11	Rear roller	1	67	Cross head bolt M5*25	8
12	Metal speaker grille	1	68	Cross recessed large pan head screw M6*15	6
13	Hand pulse	4	69	Cross recessed washer head screw M5*16	11
14	Cylinder	1	70	Cross recessed washer head screw M5*8	2
15	Transport wheel stop-pin	2	71	Cross recessed washer head screw M4*8	8
16	D-shaped axle	2	72	Cross tapping screw ST4*55	4
17	Transport wheel axle	2	73	Cross tapping screw ST4*16	70
18	Spacer	2	74	Cross tapping screw ST4*12	10
19	Edgings press plate	8	75	Cross tapping screw ST4*12	2
20	Motor cover	1	76	Cross tapping screw ST2.9*9.5	4
21	Protective cover	1	77	Cross tapping screw ST2.6*10	4
22L/R	Protective cover	1/1	78	Cross band pad self tapping screw ST2.3*8	4
23L/R	Front roller protective cover	1/1	79	Cross recessed pan head screw M4*8	4
24	Edgings	2	80	Lock washer Φ 10*1.2	16
25L/R	End cap	1/1	81	Lock washer Φ 8*1.2	12
26L/R	Protective cover	1/1	82	Lock washer Φ 6*1.2	3
27	Computer upper cover	1	83	Flat washer Φ 13* Φ 8*1.2	4
28	Computer lower cover	1	84	Flat washer Φ 10	4
29	Computer panel	1	85	Standard spring washer Φ 10	4
30	Computer panel lower cover	1	86	Nylon nut M10	8
31	Loudspeaker cover	1	87	Nylon nut M8	10
32	Computer panel joint cover	1	88	Nylon nut M6	10
33	Armrest upper cover	1	89	C shape Clasp	4
34	Armrest lower cover	1	90	Computer	1
35L/R	Armrest decorative cover	1/1	91	Shortcut key	2
36L/R	PU foam grip	1/1	92	Computer lower wire	1
37L/R	Protective cover	1/1	93	Computer extension lower wire	1
38	Running board	1	94	Computer extension upper wire	1
39	Running belt	1	95	Computer upper wire	1
40	Transport wheel	2	96	Safety key push-button sensor	1
41	Transport wheel cap	2	97	AC motor	1
42	Flat foot pad	4	98	Incline motor	1

43	Protective plug	2	99	Inverter	1
44	Cushion	4	100	Switch	1
45	Power wire buckle	1	101	Circuit breaker	1
46	Adjusting wheel	2	102	Power wire	1
47	Square end cap	2	103	Flap	1
48	Belt	1	104	Nylon spacer	4
49	Wheel	2	105	D-shaped nylon spacer	4
50	Anti-skidding mat	4	106	Loudspeaker (Optional)	2
51	Plastic pad	4	107	USB (Optional)	1
52	Hex socket screw M10*55	1	108	MP3/ Headphone (Optional)	1
53	Hex socket screw M10*55	2	109	Inductor (Optional)	1
54	Hex socket screw M10*40	1	110	Filter (Optional)	1
55	Hex socket screw M10*15	12	111	MP3 connecting wire (Optional)	1
56	Hex socket screw M8*50	4	112	Amplifier board (Optional)	1

TERMS OF WARRANTY

- Warranty period is 5 years for motor, 2 years for electrical / electronic parts and 5 years for the metal frame.
- X-TREME STORES S.A. undertakes to repair the machine free of charge in the event of damage due solely to a manufacturing fault. The warranty covers the cost of the spare parts. Replacement of spare parts or not is up to the company technicians. The customer is responsible for the control and adjustment of the machine.
- This warranty note is only valid if it is accompanied by legal proof of purchase (invoice or retail receipt). The warranty period is not extended for any reason and the transfer of it to a third party is excluded.
- Any damage is repaired as soon as possible and any claim for damages due to lack of spare parts and delay in repairing the damage is excluded. The costs of transporting the machine to or from the dealership will be borne by the customer after 6 months of purchase.
- The warranty conditions are set by the manufacturers of machinery and are governed by European regulations.
- Upon expiry of the warranty, any replacement part is covered by a 6-month warranty.

THE WARRANTY SHALL NOT APPLY:

- When the machine is used for any purpose other than home use (gyms, clubs, institutes, hotels, studios, etc.).
- When the lubrication of the walking belt is insufficient or is more than specified by the instructions for use.
- When the fault is the result of misuse, alterations, poor connection, poor maintenance, voltage fluctuations in the PPC network.
- Components damaged by user fault such as broken plastic parts, damaged belt with improper adjustment, incorrect or incomplete lubrication, damage when moving the machine.
- Components such as walking belt, side pads are considered consumables and are covered by a 6-month warranty.
- When the machine is opened or repaired by third parties.
- When the damage is caused by the buyer's negligence & the instructions for use have not been followed.
- When the machine is outdoors or exposed to sun or dust. (Dust and lint on the inside of the machine (motor roller) cause serious damage. Keep the machine clean!).
- When electronic components (console) are damaged by intense sweating or other liquid that has come into contact with or penetrated inside them.



34 koupi Avenue, Koropi

P.C.:19441 - P.O. Box 6201

Tel.: 210 66 20 921 -2 - **Fax:** 210 66 20 923

E-mail: info@xtr.gr • [f/xtrstores](https://www.facebook.com/xtrstores) •  [@xtr.gr](https://www.instagram.com/xtrstores)

Tel. for all of Greece:

801.11.15.100

www.xtr.gr